

MFOS SUB-COMMANDER Rear Panel Wiring View

Use conductive material for the front plate so that all pot bodies are grounded. Attach ground to plate too.

