## MFOS Stereo Mixer Panel - Rear Wiring View Jacks: T = Tip, R = Ring (ground), S = Switch (never used) ER2L SL2L S R S S R72 S SL2R SL1R 100K 100K $\pm$ ER2R E2SL J11 J13 R70 C4E2 C3E2 C2E2 C1E2 100K R13 100K E2SR R58 R43 R28 100K C4E1 C3E1 C2E1 EFCH4 EFCH3 EFCH2 EFCH1 ER1R E1SL C1E1 [⊏w[ R54 100K R39 100K R63 R24 R9 100K S R86 4.7K E1SR J5 PAN4L PAN3L PAN2L PAN2R PAN1L PAN1R PAN4R Put resistor R86 LED1 in shrink tube to insulate its leads. +12V HPIR 100K HPOR HPOL Ю HPIL R32 R17 R47 100K LLIN EW( 100K HPHR 0.00" PANEL SIZE W-10.50" X H-8.75" X 0.063" AL 6061