## **MFOS**

**Seven Segment Linear Envelope** Generator **Rear View Panel Wiring Diagram** 

**IMPORTANT NOTE** X3, X6, X5, X8, and X9 on the selector switch should be connected to the pot terminals with the same designator shown below. There is only one donut pad per Xn on the PC board.



Selector switches vary in form factor. Apply the description found in the circuit details to the configuration of your switch.

S4 is a DPDT Center Off Mini Toggle Switch

All threshold and slope control pots are smaller pots if using this layout. Large (24mm) pots will not fit. Amphenol style phone

iacks are shown.

