



R208 Pin 1

R210 Pin 1

R207 Pin 1

Yellow indicates where adjacent pads must be shorted by connecting the protruding leads of the components.

R200 Pin 2

These wires go to the points on the front panel diagram with the same names.