

C0 C1 C2 C3 C4 C5 C6 C7

Reed Switches and Diodes are wired as shown.

