


16 Step Analog Sequencer (panel back view)

DIGI = Digital Board Connection

ANA = Analog Board Connection

NOTE!
Switch pin numbers are for relation to the schematic only and NOT meant to correspond with any numbers on the physical switch since they may vary from manufacturer to manufacturer.



+15V for +/-15V power supply.

These are panel to PC board indicators. They relate to the drawing which shows the PC board and the corresponding connection points.