




Dual Stereo Auto-Panner



Auto-Panner 1

Auto-Panner 2



Rotor Sim


On

Off

A vertical stack of two circular knobs. The top knob is labeled 'On' and has a '1' in the top-left quadrant and a '4' in the bottom-right quadrant. The bottom knob is labeled 'Off' and has a '1' in the top-left quadrant and a '4' in the bottom-right quadrant.

Input

A circular knob with a scale from 3 to 8. The scale is marked with numbers 3 and 8. The knob has a central crosshair and radial lines.



Rotor Sim

On

Off

A vertical stack of two circular knobs. The top knob is labeled 'On' and has a '1' in the top-left quadrant and a '4' in the bottom-right quadrant. The bottom knob is labeled 'Off' and has a '1' in the top-left quadrant and a '4' in the bottom-right quadrant.

Input

A circular knob with a scale from 3 to 8. The scale is marked with numbers 3 and 8. The knob has a central crosshair and radial lines.


Rotor Toggle

Rotor Sim

On

Off

A vertical stack of two circular knobs. The top knob is labeled 'On' and has a '1' in the top-left quadrant and a '4' in the bottom-right quadrant. The bottom knob is labeled 'Off' and has a '1' in the top-left quadrant and a '4' in the bottom-right quadrant.




Rotor Sim

On

Off

A vertical stack of two circular knobs. The top knob is labeled 'On' and has a '1' in the top-left quadrant and a '4' in the bottom-right quadrant. The bottom knob is labeled 'Off' and has a '1' in the top-left quadrant and a '4' in the bottom-right quadrant.



A circular knob with a scale from 3 to 8. The scale is marked with numbers 3 and 8. The knob has a central crosshair and radial lines.

Left Out

A circular knob with a scale from 3 to 8. The scale is marked with numbers 3 and 8. The knob has a central crosshair and radial lines.

Right Out

A circular knob with a scale from 3 to 8. The scale is marked with numbers 3 and 8. The knob has a central crosshair and radial lines.

Left Out

A circular knob with a scale from 3 to 8. The scale is marked with numbers 3 and 8. The knob has a central crosshair and radial lines.

Right Out

External Pan Rate CV

A circular knob with a scale from 3 to 8. The scale is marked with numbers 3 and 8. The knob has a central crosshair and radial lines.

External Pan Rate CV

A circular knob with a scale from 3 to 8. The scale is marked with numbers 3 and 8. The knob has a central crosshair and radial lines.



MFS

ELECTRONIC MUSIC

